

# Endeavour

KIT DE MADERA • WOODEN KIT

ENGLAND XVIII



Bohras  $\phi$  8 mm  $\phi$  6 mm  
 $\phi$  3 mm  $\phi$  4 mm  
 $\phi$  2 mm  $\phi$  1 mm  
 $\phi$  0,75 mm



CONSTRUCTO®

INSTRUCCIONES  
Fotos paso a paso

INSTRUCTIONS  
Photos step by step

INSTRUCTIONS  
Photos pas à pas

BAUANLEITUNG  
Fotografien Schritt für Schritt

HANDLEIDING  
Foto's stap voor stap

ISTRUZIONI  
Fotografie passo per passo

INSTRUÇÕES  
Fotos passo a passo































































